




SUPERSTAR SS-148 Pro

Amateur Transceiver AM Mobile



User's Manual

Table of Contents

	<u>PAGE</u>
Chapter 1 Specifications	2
Chapter 2 Installation	3
Installing the Radio.....	3
Ignition Noise Interference	4
Antenna	4
External Speaker	4
Public Address	4
Chapter 3 Operation	5
Controls and Indicators	5
Front Panel	5
Rear Panel	8
Operation	9
Microphone	9
Procedure to Receive	10
Procedure to Transmit	10
Memo	11
 LIMITED WARRANTY	 Inside Back Cover

NOTE

Amateur Radio License is required to operate this device. For licensing information within the United States of America, visit <http://www.fcc.gov>, for residence of Canada, visit <http://www.rac.ca>

Chapter 1 Specifications

GENERAL

Model	SUPERSTAR SS-148 Pro
Frequency Range :	28.765 ~ 29.205
Modes	AM
Frequency Control	Phase-Lock-Loop Synthesizer
Frequency Stability	0.001%
Temperature Range	-30°C to +50°C
Input Voltage	DC 13.8 V
Antenna Impedance	50 ohms
Size	7 7/8" (W) x 11 1/8" (D) x 3 1/4" (H)
Weight	8 lb. 3 oz.

TRANSMITTER

RF Power Output	AM	100W. RMS 200W. PEP
Spurious Emissions	-50 dB	
Audio Distortion	10%	
Frequency Response	300 to 2500Hz	
Microphone	Dynamic	

RECEIVER

Sensitivity	AM	0.5 μ V for 10dB S+N/N
Squelch Sensitivity	1 μ V	
Selectivity	-35 dB	
Image Rejection	-50 dB	
Hum & Noise	40Db	
Audio Power Output	2.5W at 10% THD	

(SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE)

Chapter 2 Installation

Installing the Radio

Choose a convenient location for operation that does not interfere with driver or passenger. This radio is supplied with a universal mounting bracket. When mounting the bracket and radio to your car, make sure it is mechanically strong. Also, provide a good electrical grounding connection to the chassis of the vehicle. Proceed as follows to install the radio.

1. Locate a convenient area in your vehicle for the installation of the radio. Hold the mounting bracket with the radio in the location where the radio is to be installed. Make sure nothing will interfere with either the radio or the mounting bolts. Mark and then drill holes for the mounting bracket.
2. Most radio antennas come equipped with a PL-259 plug. Connect this plug to the ANT. Jack in the rear of the radio.
3. Extending from the rear of the radio is a fused red and black wire for the DC connections to the vehicle's electrical system. For best performance, it is strongly recommended that the red lead be taken directly to the positive terminal on the vehicle's battery and the black lead be connected to the nearest chassis ground. (Note: ***This radio is designed for vehicles with negative ground systems.***)

Connections should be made using appropriate "crimp on" lugs of a size large enough to make good contact with the bolt used to fasten to the battery and the chassis ground, It is a good safety idea to install a second fuse, in series with the red wire at the battery connection. This second fuse would provide protection in case the red wire was to "fray" or get pinched and short to the body of the vehicle, some where between the battery and the radio.

High power radios such as this one require large DC current flow when in the TX mode. Poor power connections can cause supply voltage drops that can substantially decrease the performance of your radio. A good DC connection is probably one of the most important things for getting the best transmitter performance and in some cases, least receiver noise.

Installation (Continued)

4. Mount the microphone bracket near the radio in an easily accessible spot using the two screws provided.

Ignition Noise Interference

With weak signals, you may experience interference of the signal by background noise. This radio has NB and ANL controls which will help reduce background noise from sources such as your ignition system. However, background electrical noise may come from several sources and all noise may not be eliminated. With extremely weak signals, you can operate this radio with the engine turned off, which should improve reception. If the ignition noise level is too high to allow proper operation under most conditions, you should have your installation of the radio checked by a qualified technician.

Antenna

This radio has a jack in the rear for a standard PL-259 antenna plug. If you are looking for the most range for your transmission, use a vertically polarized, quarter-wave length antenna. If antenna height is a problem, you may use a shorter, loaded-type whip antenna although you can expect some loss of transmission range.

To improve performance, your antenna should be matched to your radio. Your antenna can be adjusted so that it matches your radio.

External Speaker


The external speaker jack (EXT. SPK) on the rear panel is used for remote receiver monitoring. The external speaker should have 8 ohms impedance and be able to handle at least 4watts. When the external speaker is plugged in, the internal speaker is disconnected.

Public Address

To use the Public Address (PA) function, first connect an external speaker to the PA. SP. Jack on the rear of the radio. See the above specifications for a proper external speaker. Keep the speaker away from the microphone to avoid acoustic feedback.

Chapter 3 Operation

Control and Indicators Front Panel



1. **MICROPHONE JACK:** Used to connect microphone for voice source.
2. **SQUELCH CONTROL:** This control is used to control or eliminate receiver background noise in the absence of an incoming signal. For maximum receiver sensitivity, it is necessary that the control be adjusted only to the point where the receiver background noise is eliminated. Turn fully counterclockwise and then slowly clockwise until the receiver noise just disappears. Any signal to be received must now be slightly stronger than the average received noise. Further clockwise rotation will increase the threshold level that a signal must overcome in order to be heard. Only strong signals will be heard at a maximum clockwise squelch setting.
3. **ON/OFF VOLUME CONTROL:** Turn clockwise to apply power to the radio and to set the desired listening level.

Operation (Continued)

4. **RF GAIN CONTROL:** This control is used to reduce the gain of the RF amplifier under strong signal conditions.
5. **MIC GAIN CONTROL:** Adjust the microphone gain in the transmit mode. This control is used to set the audio level of the microphone for maximum performance and clarity.
6. **ECHO/TIME CONTROL:** The ECHO control is used for echo effect. The TIME control is used to control the intervals of the echo sound.
7. **FREQUENCY SELECTOR:** This control is used to select a desired transmit and receive frequency.
8. **FRONT PANEL METER:** The front panel meter allows the user to monitor signal strength, RF output power, SWR level and the AM Modulation level.
9. **RF POWER CONTROL:** This control enables adjustment of RF power output continuously up to the rated output power.
10. **TALKBACK/OFF CONTROL:** Adjust this knob for desired volume of Talkback. This is used to monitor your own voice. Or example, you could use this feature to compare different microphones.
11. **Fr. POOL:** The *Frequency Pool* allows the user to select the desired segments of frequencies.
12. **SWR/MOD/PWR:** In the SWR/MOD/PWR position, the meter swings proportionally to the strength of the received signal. In PWR position when transmitting, the meter indicates relative RF output power. When in the SWR position, the Standing Wave Ratio (SWR) of your antenna. There are no adjustment because the SWR circuit in this radio calibrates itself automatically. When the switch is in the MOD


Operation (Continued)

position, the green scale on the meter indicates your percentage of modulation. The operates in AM only, not in SSB.

13. **PA/AM/AM+RB:** Select the mode of operation. In the PA position, the radio acts as public address amplifier. Your voice will come out of the speaker that is plugged into the PA. SP. jack on the rear panel. The radio does not operate when you are in the PA mode. In the AM position, the PA function is disabled and the radio will transmit and receive on the speaker that is connected. In the AM+RB position radio will receive and transmit with Roger Beep function.
14. **NB/ANL SWITCH:** In the NB/ANL position, the RF Noise Blanker and the automatic Noise Limiter in the audio circuits are also activated. The Noise Blanker is very effective in eliminating repetitive impulse noise such as ignition interference.
15. **DIM SWITCH:** This switch is used to select the brightness of display.
16. **CH19 SWITCH:** This switch allows you to select channel 19 instantly.
17. **RB LIGHT:** This lights red when the Roger Beep is on
18. **CHANNEL DISPLAY:** The channel display indicates the current selected channel.
19. **SWR LIGHT:** This LED light red when your SWR is higher than about 3:1. This is not an exact indicator of 3:1 SWR, but it is an indication that you should check your SWR reading.
20. **TX/RX LED:** The red LED indicates the radio is in the transmit mode. The blue indicates the radio is in the receive mode.

Operation (Continued)

Rear Panel



1. **POWER:** This accepts 13.8 VDC power cable with built-in fuse. The power cord provided with the radio has a black and red wire. The black goes to negative and the red goes to positive.
2. **ANTENNA:** This jack accepts a 50 ohms coaxial cable with a PL-259 style plug.
3. **PA SP:** This jack is for PA operation. Before operating, you must first connect a PA speaker (8 ohms, 4w) to this jack.
4. **F.C.:** This connector is used for connecting an external frequency counter which indicates the frequency of the selected channel.
5. **EXTERNAL SPEAKER:** This jack accepts a 4 - 8 ohm, 5watt external speaker. When the external speaker is connected to this jack, the built-in speaker will be disable.

Operation (Continued)

Operation

A. Microphone


The receiver and transmitter are controlled by the push-to-talk switch on the microphone. Press the switch and the transmitter is activated, release switch to receive. When transmitting hold the microphone two inches from the mouth and speak clearly in a normal “voice”. The transceiver comes complete with low-impedance dynamic microphone.

For best results, the user should select a low-impedance dynamic type microphone or a transistorized microphone.

The microphone should provide the functions shown in schematic below.

4 WIRE MIC CABLE

<u>Pin Number</u>	<u>Mic Cable Lead</u>
1	Audio Shield
2	Audio Lead
3	Transmit Control
4	Receive Control



Transceiver Microphone Schematic Diagram

Operation (Continued)

B. Procedure to Receive

1. Be sure that power source, microphone and antenna are connected to the proper connectors before going to the next step.
2. Turn unit on by turning **VOL** knob clockwise.
3. Set the **VOL** for a comfortable listening level.
4. Set **MODE** switch to the desired operation mode.
5. Listen to the background noise from the speaker. Turn the **SQ** knob slowly clockwise until the noise just disappears. The **SQ** is now properly adjusted. The receiver will remain quiet until a signal is actually received. Do not advance the control too far, or some of weaker signals will not be heard.
6. Set the **CHANNEL** switch to the desired channel.
7. Set the **RF** gain control fully clockwise for maximum **RF** gain.

C. Procedure to Transmit

1. Select the desired channel of transmission.
2. Set the **MIC GAIN** to the level that will best suit your individual use.
3. If the channel is clear, press the push-to-talk switch on the microphone and speak in a normal voice.

Memo



Memo

[A series of horizontal lines for writing, starting with a thick black bar immediately below the title 'Memo', followed by multiple thinner lines.]

PRINTED IN MALAYSIA
P/N: A382516099